


INSTALLATION GUIDE

PREMIUM DC WALL CONTROL



Model Parameters:-

4S4000WH Premium WIFI DC Wall Control to suit all Four Seasons DC Ceiling Fans


CAUTION
READ INSTRUCTIONS
CAREFULLY FOR SAFE
INSTALLATION AND FAN
OPERATION




**MUST BE
INSTALLED BY
A LICENSED
ELECTRICIAN**

INSTALLATION


Installation Steps:




- 1 Pry up the front panel with a screwdriver




- 2 Remove the panel



- 3 Insert the wire into the corresponding screw hole




- 4 Install the wall controller in the junction box and secure it with screws



- 5 Reattach the front panel

PLEASE NOTE: Check for any damage to the wall controller prior to installation. Physical damage such as marks and scratches are not covered by the in-home warranty. In this case, please contact the Four Seasons support team to discuss replacement parts.

REMOTE CONTROL OPERATION



PAIRING METHOD

If the emitter cannot control the fan, you need to pair it with the receiver.

1. Switch the power ON
2. Within 10 seconds, press and hold the emitter's button  for 3 seconds
3. A long "beep" will confirm successful pairing

IMPORTANT: Pairing is not possible if more than 10 seconds have passed since powering on

Troubleshooting tips:

- Ensure that the wires are connected properly
- Check whether other remote-controlled products nearby may be interfering (devices with the same frequency can cause disruptions)
- When installing the fan, make sure the ceiling cover does not press against the antenna or wires, as this may cause damage or short-circuiting

WARRANTY INFORMATION

For technical support, please contact Four Seasons customer service hotline at **(02) 8778 7570**.

If you suspect any issues with the installation, please contact your installer to resolve the matter. In case you believe the issue is related to a manufacturing defect, you can file a warranty claim by visiting <https://www.fourseasonsliving.com.au/warranty-claim-form> or scan the below QR code.

IMPORTANT NOTICE: All claims for warranty must be accompanied with the following three documents:

1. Copy of the Installation Receipt OR Tax Invoice OR Certificate of Compliance for the installation of the Four Seasons product from the installing electrician
2. Copy of the Purchase Receipt for the Four Seasons product, and accessories such as extension rod or remote control
3. Submit an online warranty claim form. Please ensure that the purchaser's full name and contact details are clearly stated, in addition to the full nature of the fault and the product code.

It is the responsibility of the purchaser to keep the documents required for a warranty application of the warranty period.

Customer Service operates between 8AM to 4PM EST Monday to Friday.

Customer Service Number: (02) 8778 7570

